

TF Automatic Gate Notes

1. The TF gate opens four ways:

- With radio remotes**
- A valid code in the keypad**
- Metal nearby the free exit sensor**
- Fire, EMS or Police vehicle with Opticom**

2. The gate must have 115AC power to run.

3. When triggered, the gate will open and stay open for about 2 min and then close. There is a beeping warning while the gate is closing. There are no safety switches. Do not go near the gate while it is in motion.

4. Be aware that the gate could suddenly close when encountering other vehicles at the gate. Beware of situations where:

A: A vehicle is entering from the road and has opened the gate. If an exciting vehicle comes near the free exit sensor, the gate will rapidly close.

B: If two vehicles pass while in the vicinity of the free exit sensor, and the gate is open, the gate may rapidly close.

5. The gate is equipped with a video recording system that takes motion-triggered snapshots of activity near the gate.

